

QDaedalus

Augmentation of Total Stations by CCD Sensor for Automated Contactless High-Precision Metrology

Sébastien Guillaume¹, Beat Bürki¹, Sylvain Griffet², Hélène Mainaud-Durand²

1. Institut für Geodäsie und Photogrammetrie, **ETH Zurich**, Switzerland
2. European Organization for Nuclear Research, **CERN Geneva**, Switzerland



A Very Short Overview of 3D Commercial Metrological Systems

CMM: Coordinates Measurement Machine

$\sigma < 1 \mu\text{m/m}$ range < 1-2 m



© Leitz

Measurement Arm

$\sigma \sim 10 \mu\text{m/m}$ range < 5 m



© Romer

Laser Tracker with Absolute EDM

$\sigma \sim 7.5+3 \mu\text{m/m}$ range < 100 m



© Leica Geosystems

Laser Tracker with Interferometer


$\sigma \sim 7.5+3 \mu\text{m/m}$ range ~ 150 m



© Leica Geosystems

Close-Range Photogrammetry

$\sigma \sim 15 \mu\text{m/m}$ range < 50 m



@ Aicon

Laser Scanner

$\sigma \sim 1 \text{ mm}$ range $\sim 100 \text{ m}$




@ Leica Geosystems

The Measurement System

QDaedalus

QDaedalus

- High Precise : $< 10 \mu\text{m/m}$
- Touchless
- Fully Automated
- High Rate Measurements : 30 Hz
- Low-cost
- Open & Flexible Software



QDaedalus: System Components


- Main Components
 - Total Station
 - CCD Sensor
 - Focusing Mechanics
 - Software (Qt c++)
- Additional Components
 - Front Lens (for long range obs. $> 13 \text{ m}$)
 - Interface box (CCD Triggering synchronization of multiple system)
 - External GPS Receiver (for Absolute CCD Timing)



QDaedalus: System Components

■ Main Components

- Total Station
- **CCD Sensor**
- Focusing Mechanics
- Software (Qt c++)



- 1024 x 768 pixel (4.65 x 4.65 μm)
- Fire Wire connection (30 fps)
- External Trigger
- Black and White

1 pixel = 4 arcsec


■ Additional Components

- Front Lens (for long range obs. > 13 m)
- Interface box (CCD Triggering synchronization of multiple system)
- External GPS Receiver (for Absolute CCD Timing)

QDaedalus: System Components

■ Main Components

- Total Station
- CCD Sensor
- **Focusing Mechanics**
- Software (Qt c++)




■ Additional Components

- Front Lens (for long range obs. > 13 m)
- Interface box (CCD Triggering synchronization of multiple system)
- External GPS Receiver (for Absolute CCD Timing)

QDaedalus: System Components

- Main Components

- Total Station
- CCD Sensor
- Focusing Mechanics
- **Software (Qt c++)**




- Additional Components

- Front Lens (for long range obs. > 13 m)
- Interface box (CCD Triggering synchronization of multiple system)
- External GPS Receiver (for Absolute CCD Timing)

CCD-Space ↔ Theodolite-Space

Calibration

Calibration



Calibration

Affine Transformation (6 parameters)


$$\begin{array}{l}
 r_{object} \\
 z_{object}
 \end{array}
 =
 \begin{array}{l}
 r_p \\
 z_p
 \end{array}
 \underbrace{\begin{array}{l}
 \frac{1}{\sin z_p} [a_{11} \cdot (x_{object} - x_p) + a_{12} \cdot (y_{object} - y_p)] \\
 a_{21} \cdot (x_{object} - x_p) - a_{22} \cdot (y_{object} - y_p)
 \end{array}}
 \begin{array}{l}
 \delta r \\
 \delta z
 \end{array}$$

object
angles

telescope
readings

calculated Hz and V
corrections

Calibration



Identification & Extraction of Objects

Optical Target Recognition

OTR: Least-Squares Template Matching




precision < 0.1 pixel = 0.4 arcsec = 2.5 μm/m

OTR: Centroid Operator






precision < 0.1 pixel = 0.4 arcsec = 2.5 μm/m

OTR: Robust Circle Matching Operator




precision < 0.1 pixel = 0.4 arcsec = 2.5 $\mu\text{m}/\text{m}$

OTR: Robust Ellipse Matching Operator



precision < 0.1 pixel = 0.4 arcsec = 2.5 $\mu\text{m}/\text{m}$

OTR: Robust Ellipse Matching Operator




precision < 0.1 pixel = 0.4 arcsec = 2.5 μ m/m


Practical Experiment of QDaealus at CERN

Automatic Microtriangulation of Linear Collider Components

Future = electron-positron Linear Collider




Future = electron-positron Linear Collider



➔ more than 20 000 modules in total
to be measured !


Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation

1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process




Automatic Microtriangulation


1. Import approximate positions of station and targets
2. Camera, focus, circle matching parameters... definition
3. Start measurements, fully automatic process
4. Adjust micro-triangulation network




Automatic Microtriangulation




Automatic Microtriangulation



Automatic Microtriangulation



Automatic Microtriangulation



Automatic Microtriangulation

Empirical standard deviation and differences with respect to the Coordinates Measurement Machine (CMM $\sigma = 1\mu\text{m}$) of the points measured with the system QDaedalus.

	Empirical Standard Deviation			Differences with Coordinate Measurement Machine			
	sX [microns]	sY [microns]	sZ [microns]	dX [microns]	dY [microns]	dZ [microns]	d3D [microns]
MC1-M3	5	6	9	-3	-2	1	4
MC1-M4	5	4	7	8	-6	7	12
MC1-M5	4	3	6	1	-5	-10	11
MC1-M6	4	4	5	-11	9	-5	15
MC1-M7	4	5	4	2	7	4	8
MC1-M8	4	6	3	3	-3	3	5
MC2-M3	3	5	4	1	8	2	9
MC2-M4	3	4	4	5	16	0	17
MC2-M5	4	3	6	0	8	-7	11
MC2-M6	4	3	5	-5	-2	4	7
MC2-M7	5	5	8	-8	-8	-4	12
MC2-M9	6	11	10	7	-23	6	24

Oscillation of a Bridge after Passage of a Truck

Kinematic Measurements with QDaedalus


Measurements carried out by HEIG-VD

Kinematic Measurements



@ HEIG-VD

Kinematic Measurements



Summary and Conclusions

The system QDaedalus

- can be mounted without mechanical changes at the Total Station
- enables Optical Target Recognition (OTR) using circle operator and pattern matching
- enables accurate time tagging of the observations
- enables real-time dynamic monitoring of displacements, vibrations, and scintillations
- enables tracking of moving objects with a frame rate of up to 30 Hz including time stamps
- is a versatile tool for numerous indoor and outdoor applications
- further object operators and other improvements are under development


Thanks for attention

guillaume@geod.baug.ethz.ch

www.ggl.ethz.ch




Automatic Microtriangulation




Removing the eyepiece and mounting a CCD camera evokes optical blur



Meas. Range = 1.5 to 13 m






Mounting a divergent lens in front of the objective

Meas. Range = 2 m to ∞










Evolution of the refraction coefficient during 16 hours across Elbe River



Variations of ΔH during 16 hours across Elbe River due to Refraction

